



| description   | model  | retail price       |            |
|---|--|--------------------|------------|
|   |  | EURO               | (VAT)      |
| <b>PRE-AMP</b>  |  |                    |            |
|    |  | <b>PRE-FP</b>      | <b>190</b> |
| Recharge PREAMP   |  |                    |            |
|    |  | <b>PRE-DI</b>      | <b>225</b> |
| Recharge PRE-DI   |  |                    |            |
|    |  | <b>OCTAVE</b>      | <b>215</b> |
| Octaver for clarinet & violin   |  |                    |            |
|    |  | <b>Hybrid</b>      | <b>180</b> |
| Preamp system   |  |                    |            |
|   |  | <b>Echo Hybrid</b> |            |
| Equaliser & Echo/delay & DI   |  |                    |            |
|  |  | <b>EQ Reverb</b>   | <b>240</b> |
| Equaliser & Reverb & DI   |  |                    |            |
|  |  | <b>BOU Reverb</b>  | <b>180</b> |
| Bouzouki Reverb   |  |                    |            |
|  |  | <b>PRE - P</b>     | <b>95</b>  |
| Preamplifier (volume, gain, bass, treble)   |  |                    |            |
|  |  | <b>PRE - B</b>     | <b>85</b>  |
| Preamplifier (volume, gain, bass, treble)   |  |                    |            |
|  |  | <b>HEAD PR1</b>    | <b>65</b>  |
| Headphone Amplifier   |  |                    |            |
|  |  | <b>PRE - PM</b>    | <b>76</b>  |
| Pickup & MIC Mixer- Preamp (vol, tone)  |  |                    |            |
|  |  | <b>PRE - PZ</b>    | <b>70</b>  |
| Piezo - pickup Preamp (voume, gain, tone)   |  |                    |            |
|  |  | <b>PRE - INS</b>   | <b>64</b>  |
| Ppickup Preamplifier (voume, tone)  |  |                    |            |



| description  | model              | retail price |
|--|--------------------|--------------|
|  |                    | EURO (VAT)   |
| <b>Wireless - Effect</b>   |                    |              |
|  <p>Wireless Instrument / In Ear</p>  | <b>Win Ins</b>     | <b>132</b>   |
|  <p>Wireless Drum Mic</p>   | <b>Win DM</b>      | <b>124</b>   |
|  <p>Wireless Microphone</p>   | <b>Win Mic</b>     | <b>120</b>   |
|  <p>Wireless Microphone</p>   | <b>Win HM</b>      | <b>122</b>   |
|  <p>Wireless In EAR &amp; Instrument</p>                                   | <b>Win EAR</b>     | <b>135</b>   |
|  <p>Wireless Instrument (gain) &amp; In Ear</p>                            | <b>Win Ins-Ear</b> | <b>140</b>   |
|  <p>Wireless Instrument</p>   | <b>WinG</b>        | <b>75</b>    |
|  <p>Endpin jack preamplifier &amp; piezo bar &amp; Volume / tone/gain</p> | <b>ENJC -P</b>     | <b>110</b>   |
|  <p>Endpin jack preamplifier &amp; Volume / tone/ gain</p>                | <b>ENJ - C</b>     | <b>72</b>    |
|  <p>Endpin jack preamplifier &amp; gain</p>                               | <b>ENJ - G</b>     | <b>50</b>    |
|  <p>Endpin jack preamplifier</p>  | <b>ENJ</b>         | <b>40</b>    |
|  <p>Active phantom power cable</p>  | <b>ACTC</b>        | <b>40</b>    |
|  <p>Power 9 Volt</p>  | <b>POWER 9</b>     | <b>20.5</b>  |
|  <p>Power pack 4 x 9 Volt</p>   | <b>POWER 4X9</b>   | <b>45</b>    |
|  <p>Power pack 5Volt Micro USB</p>  | <b>PM-USB</b>      | <b>12</b>    |